




Air-operated Hydraulic Pressure Jack


FPL-351

(Operation instruction)



Minimum Height:360mm
Hoisting Height:250mm

**WINDPIPE
CONNECTION**




Code	PART NAME	QTY	Code	PART NAME	QTY	Code	PART NAME	QTY
1	Operation Rod	1	9	Adaptor	1	17	O Ring	3
2	Extension Rod 50mm	1	10	Adaptor	2	18	Oil Cylinder	1
3	Extension Rod 150mm	1	11	Lock Code	2	19	M10 Spring Gasket	4
4	Extension Rod 100mm	1	12	Windpipe	1	20	M10 Screw	4
5	Adaptor	3	13	Boosting System-D70	1	21	M8 Spring Gasket	4
6	Fixed shaft	1	14	Oil Pipe	1	22	M8 Screw	4
7	Outer Retainer Ring	2	15	Windpipe	1	23	Windpipe	1
8	Adaptor	1	16	Windpipe	1	24	Adaptor	

AJ-35T1N EXPLODED VIEW

Picture A


Boosting System-D70



Code	PART NAME	QTY	Code	PART NAME	QTY	Code	PART NAME	QTY
1	Adaptor	1	18	Spring	2	35	Glgy Ring	2
2	Retaining Ring	1	19	O Ring	1	36	Piston	1
3	O Ring	1	20	Screw-plug	1	37	Sealing Gasket	1
4	Piston Cover	1	21	O Ring	1	38	Strengthened Piece	1
5	O Ring	1	22	O Ring	1	39	Screw	1
6	Fuel Return Piston	1	23	Shaft Sleeve	1	40	Screw	2
7	Fuel Return Thimble	1	24	IDI-9*19*8	1	41	Vent Cover	1
8	Fuel Return Spring	1	25	Pump Gasket	1	42	Screw-plug	1
9	Hydraulic Intergration	1	26	IDI-9*17*5	1	43	Boosting cylinder	1
10	Gasket	3	27	Hydraulic Pump	1	44	O Ring	1
11	Screw-plug	1	28	Spring	1	45	Cover	1
12	Steel Ball	4	29	Piston rod	1	46	Safe Valve	1
13	Spring	1	30	Cover	1	47	Adaptor	1
14	O Ring	2	31	Cover	1	48	Adaptor	1
15	Screw-plug	1	32	O Ring	1	49	Retaining Ring	1
16	Adaptor	1	33	Sealing kit	1			
17	Screw-plug	2	34	Piston	1			

Boosting System Drawings
Picture B


Oil Cylinder



Code	PART NAME	QTY	Code	PART NAME	QTY
1	O Ring	1	9	O Ring	1
2	Screw-plug	1	10	Oil Cylinder	1
3	Bottom	1	11	Wearing Ring	1
4	Wearing Ring	1	12	Dustband	1
5	Glyd Ring	1	13	Short Extension Rod	1
6	O Ring	1	14	M8 Spring Gasket	1
7	Retaining Ring	1	15	Screw	1
8	Piston	1	16	Adaptor	1

Oil Cylinder Drawings
Picture C


Frame



Code	PART NAME	QTY	Code	PART NAME	QTY
1	Frame	1	14	Nail	4
2	Label	1	15	Nameplate	1
3	screw	2	16	Adaptor	3
4	Screw-Plug	2	17	Adaptor	1
5	Handle	1	18	Adaptor	1
6	Outer Retainer Ring	2	19	Adaptor	1
7	Truckle Gasket	2	20	Label	1
8	Truckle	2	21	Label	1
9	Label	1	22	Label	1
			23	Label	1
11	Protected plate	1	24	O Ring	1
12	Screw	8	25	Screw-plug	1
13	Protected Plate	1	26	Label	1

Frame Drawings
Picture D


Operation Rod



Code	PART NAME	QTY	Code	No.	PART NAME	QTY	Code	PART NAME	QTY
1	Hand Valve	1	13-1		Valve Body	1	25	Screw	1
2	Adaptor	2	13-2		Glass	1	26	Handle	1
3	Windpipe	2	14		Filter Instruction	1	27	Spring Gasket	2
4	Adaptor	1	15		M5 Bolt	2	28	Gasket	2
5	Adaptor	1	16		Adaptor	1	29	Label	1
6	Spring Gasket	3	17		Label of Caution	1	30	Label	2
7	Screw	1	18		Frame of Operation Rod	1	31	Label	6
8	Adaptor	2	19		Instruction	1	32	Screw	2
9	Lock Code	2	20		Windpipe	1	33	Bumper of operation rod	1
10	Oil Pipe	1	21		Spring tube	2	34	Oil mist resistance pot	1
11	Handle Cover	2	22		Windpipe	1	35	Windpipe	1
12	Screw	2	23		Spring tube	1			
13	Filter	1	24		Windpipe	1			

Operation Rod Exploded View
Picture E

Hand Valve



Code	PART NAME	QTY	Code	PART NAME	QTY
1	Label	1	8	Valve Core	1
2	Cover of Hand Valve	1	9	O Ring	1
3	Return Spring of Hand Valve	2	10	Conversion Base	1
4	Controlling Handle	1	11	Spring Gasket	1
5	Cover of Reversing Valve	1	12	Screw	1
6	O Ring	2			
7	Shaft	1			

Hand Valve
Picture F